



TOMS OFFROAD

#6740 - Body Mount Bushing & Hardware Installation

Step 1. Park bronco on level ground and set e-brake and chock all four wheels.

Step 2. Remove one side of the old hardware. If necessary, cut the old hardware using a reciprocating saw (Ex. Sawzall). Loosen opposite side.

Step 3. Slowly jack one side of the body away from the frame making sure not to damage the body. (Disperse the load by using something to increase the surface area of the jacking point)

Step 4. Reinstall new bushings and hardware. Leave hand tight until all eight mounting points are in place, then tighten. Starting with the shortest bolts in the front two locations, the next sets of bolts increase in length as you get toward the rear of the bronco.

Note: New bushings and hardware can change body gaps and door alignment. When bushings are being replaced, check all fitment and add shims if necessary.

