



## #0928 Receiver Hitch Installation Instructions

### TOOLS NEEDED:

Drill & 1/2" Drill Bit

3/4" Wrench or Socket & Ratchet

### PARTS INCLUDED:

1 - Receiver Hitch

2 - Backing plate

6 - Bolts, 1/2" x 1.5" Grade 8, NF

### INSTALLATION:

1. Take off any existing bumper and frame mounted skid plate.
2. Clean underside of frame and cover with a rust inhibitor if desired.
3. Mock up receiver hitch in place using existing elongated drain hole in bottom of frame to match with the hole furthest back in the receiver hitch (refer to picture below). Mark the other two holes in receiver hitch and prepare to drill. Repeat on other frame rail.
4. Drill the existing 4 holes needed using a 1/2" drill bit.
5. Slide plates with welded nuts down inside frame rail lining them up with the three holes in the frame rail. Repeat on the other frame rail.
6. Bolt receiver hitch to frame using hardware provided. If a factory skid plate is being used, sandwich mounting tabs of skid plate between the frame and receiver hitch. Torque spec:

